



# washer•watcher®

## easy installation instructions

### Step 1:

Plug your new WasherWatcher control module into a suitable grounded 115 VAC outlet. The outlet must be within 6 feet of the laundry tub. To ensure it is installed correctly, the WasherWatcher will do a self-check. The alarm will beep three times and the LED on the front will flash red two times.

### Step 2:

Plug the washer power cord into the WasherWatcher control module. (see figure 1)

### Step 3:

Position the water sensor at the end of the washer discharge hose so that the inside ridge of the sensor fits snugly against the end of the hose. Secure the sensor to the discharge hose with the tie wrap. (see figure 2) Note: The end of the hose should be a minimum of 8" from tub base.

### Step 4:

**Test the WasherWatcher by performing the following procedure:**

Start the washer on a normal wash cycle. Then submerge the tip of the water sensor into a cup of tap water. This should cause the LED on the front of the WasherWatcher control module to switch from **GREEN** to **RED** and the high water alarm to start beeping. When the LED is **RED**, the control module shuts off the washing machine. Remove the cup of water. The high water alarm should immediately stop beeping and, after a short period of time, the LED should switch back to **GREEN** and the washing machine should resume its cycle. It is recommended to periodically test the WasherWatcher. If the test results differ from what has been described, check the mounting of the control module and the placement of the water sensor. The control module needs to be firmly plugged into the outlet, and the sensor tip needs to be in contact with the water in order to detect the high level correctly.




figure 1.




figure 2.

WasherWatcher® One-year Limited Warranty

STAK Enterprises Inc. warrants the WasherWatcher to be free from defects in materials and workmanship under normal use and service for a period of one year from the date of purchase. STAK Enterprises Inc. makes no other express or implied warranty for this device. No agent, representative, dealer, or employee of STAK Enterprises Inc. has the authority to increase or alter the obligations or limitations of the warranty. The company's obligation of this warranty shall be limited to the repair or replacement of any part of the WasherWatcher which is found to be defective in materials or workmanship under normal use and service during the one year period commencing with the date of purchase. During the initial 90-day period commencing with the date of purchase, such repair or replacement shall be made without charge. During the remaining period of the warranty, such repair or replacement shall be made at a charge to the customer not to exceed the manufacturer's cost. Units in need of repair should be returned, shipping prepaid, to Customer Service Department, STAK Enterprises Inc., 471-A Jennings Drive, Lake-in-the-Hills, IL 60156

THE DURATION OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THAT OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSES, SHALL BE LIMITED TO THE PERIOD OF ONE-YEAR COMMENCING WITH THE DATE OF PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.